sistema®

Sistema® Home™ baskets are a versatile and stylish storage solution. Whether you need to organise your laundry, bathroom, kitchen or bedroom, there is a Sistema® basket to meet your needs.

Stack multiple baskets by simply clicking the handles inwards, or nest neatly together when not in use to save space in your home. The sturdy carry handles allow for comfortable, secure transporting.



Use and Care

To keep your Sistema® Home™ basket looking its best, the following are recommended:

Use & Care Guidelines

- Clean the baskets regularly to maintain their quality. Use a mild detergent and warm water. Avoid using abrasive cleaners or scrub brushes as they may scratch the surface.
- Dry them thoroughly by air drying or wiping down with a clean, dry cloth.
- Store them in a cool, dry place when not in use. Avoid exposure to direct sunlight or extreme temperatures as it may cause the products to warp or fade.
- When using the baskets, place them on a flat, stable surface. Avoid placing on uneven surfaces to prevent tipping over.
- Distribute items inside evenly. Do not overload them beyond their capacity.
- Always lift them using both hands. Use the handles for safer and easier transportation.

Warnings

- Keep out of reach of children to prevent accidents.
- Do not store very heavy items that could cause breakage or instability.
- Avoid storing sharp objects that could puncture or scratch.







