

sistema[®] to go[™]

Sistema[®] TO GO[™] lunch bags are insulated to keep lunch warm or cold, and fold flat when not in use to save valuable space. They feature food safe lining, easy to wipe clean, durable zip closures, and are available in a range of fashionable colours.



Use and Care

To keep your Sistema[®] TO GO[™] lunch bag looking its best, the following are recommended:

Care Guidelines

- Remove all labels/packaging before use.
- Hand wipe with soft cloth and warm soapy water before and between uses. Do not immerse in water.
- Do not use boiling water, chemicals, abrasive cleaners, or scrubbers to clean.
- Allow the lunch bag to completely air dry before storing.
- Empty lunch bag after use to prevent stains and odour retention.
- Bring the zipper sides together before zippering and closing. Do not force the zipper to close.
- Do not use in microwave, dishwasher, washing machine, or dryer.

Packaging tips for cold food and beverages

- Store food in containers or sealed bags.
- Pre-chill the food and beverages before placing inside the bag.
- When using an ice pack, place it at the centre and surround with food or beverages.

Packaging tips for warm food

- Store food in containers or sealed bags.
- Wrap casseroles or dishes in a towel to keep them warm and to avoid direct contact with the bag lining.
- Do not store HOT food as it may melt or damage the bag lining.

